



Putting People First Since 1948



Alert #: SA 16-16

Date: 11/29/16

Hazard Identification

The Hazard Id (L.A.W.) is a critical first step of the L.I.F.E. Process and must be completed during the pre-job walkthrough for each task. During the walkthrough, it is important to thoroughly look for hazards **at the work site** and document all that are identified on the L.A.W. The hazards must then be mitigated within the WP/SEA utilizing the EBI's. If the scope of the job changes for any reason, or if any new hazards are introduced it is important to stop and reevaluate and upgrade the WP/SEA. Recently a crew was setup for sand blasting operations and upon release of the blast hose trigger, the dead man engaged causing pressure in the sand pot. During inspection of the issue, an unexpected release of pressure caused sand particles to get into an employee's eyes.



Things to Remember:

- Before any job begins OR if there is a change in the scope of the job, you must have an adequate WP/SEA completed/updated. ALL hazards must be identified on the LAW in order to have an adequate WP/SEA.
- Wear your PPE!!



***Report all incidents immediately to the GIS
Hotline 1-855-543-5163.***

SAFETY ALERT