MINIMUM REQUIREMENT

60



WP/SEA MINIMUM REQUIREMENTS Painting Welded Areas



MEMORY JOGGERS Ensure that the following conditions are met before proceeding. If not met, address on WP/SEA. Communicate the "RIGHT TO STOP WORK AUTHORITY POLICY" and is exercised by all crewmembers and other \geq personnel that believe something or some condition has changed. The job is to be stopped and accessed before proceeding. The WP/SEA may need to be modified or a new WP/SEA maybe required before starting the work task again. \triangleright Make sure buffer wheel on grinder is in good shape and dead man switch has been disabled. \triangleright Make sure paint is in its original properly marked can or in an approved container (for 1 time use if not in original can). Ensure that drop clothes are on site and readily available. ۶ Check extension cord for cuts or burns and replace if necessary. \geq \triangleright Ensure extension is plugged into a GFCI circuit. ۶ Put up wind wall if winds are excessive. \triangleright If working at heights in excess of 6', complete and review JSEA Minimum Requirements on Fall Protection. **MINIMUM REQUIREMENTS** 1) Verify All conditions identified in the "Memory Joggers" section are met (or are not applicable); if ANY are not met, STOP and add the necessary step to the WP/SEA to ensure the safest method possible. 2) Route extension cord in a way that won't cause a tripping hazard. 3) Using a face shield, carefully buff area to be painted. Clean area with clean dry cloth, making sure all loose material is wiped off. 4) Put drop cloth under area to be painted, fasten drop cloth to deck so it does not fly away causing an environmental hazard 5) (may fly overboard). Using a brush, paint area using even strokes, being careful not to apply too much paint. 6) 7) Apply caution tape around wet paint area to avoid others to come in contact with the paint. Unplug grinder and extension cord and roll up. 8) Move to next area to be painted and repeat Steps 2 through 8 until all areas are painted. 9) 10) Pick up tools and droop cloths in their proper holding area.

11) Leave caution tape up until all paint had dried.