

WP/SEA MINIMUM REQUIREMENTS SECURING TUBING



MEMORY JOGGERS

Ensure that the following conditions are met before proceeding. If not met, address on WP/SEA.

- Communicate the "RIGHT TO STOP WORK AUTHORITY POLICY" and is exercised by all crewmembers and other personnel that believe something or some condition has changed. The job is to be stopped and accessed before proceeding. The WP/SEA may need to be modified or a new WP/SEA maybe required before starting the work task again.
- Review the scope of work with all crew members to ensure a clear understanding among the crew.
- Inspect all tools and equipment prior to begin of work
- > Obtain Hot Work Permit if needed and write WP/SEA
- > Scan work area for obstructions prior to begin of work.
- ➤ Verify employees are wearing complete PPE.
- > Route all extension cords out of walk ways and caution off if needed.

MINIMUM REQUIREMENTS

- 1) Verify **All** conditions identified in the "Memory Joggers" section are met (or are not applicable); if **ANY** are not met, **STOP** and add the necessary step to the WP/SEA to ensure the safest method possible.
- 2) Inspect all tools and equipment prior to beginning work
- 3) Perform gas detection if needed.
- 4) Route extension cords out of path of work area. Make sure to use GFCI's with all electrical tools.
- 5) Ensure proper eye and hand protection prior to beginning work
- 6) Lay out clips and drill and cut clips
- 7) File any rough edges on clips.
- 8) Cut isolation rubber for clips using diagonal cutters or electrical succors.
- 9) When using ladders, secure ladder and do not over extend from center of ladder.
- 10) When working at heights or near hand rails wear fall protection and ensure rescue plan is in place.
- 11) Install clips by bolting into tray to hold tubing in place
- 12) If using prefab tubing gang clips bolt clips to tubing or secure down to tray.
- 13) When securing with banding straps ensure not cut hands on sharp edges and fold tubing over clip.
- 14) Return all unused hardware and or tools to proper storage.
- 15) Roll up all cords and return them to storage area.
- 16) Clean up work area and dispose in proper bins.